

CRACKLE EFFECT

EFFECT LACQUER FOR A SPECIAL VINTAGE LOOK

For the special crackle- or used-look. Prior coating of the object is necessary with colors of Montana GOLD (recommended) or Montana WHITE (the thicker the base coat the stronger the effect). Give at least 45min but not more than 24hours drying time to the base coat before applying CRACKLE effect. While spraying change directions (cross-coat) for best coating results. After extensively applying CRACKLE to your primed area, the distressing process will begin to occur. CRACKLE can be top-coated when fully dry and cured (after 24h) with Montana GOLD, BLACK, WHITE, Montana ACRYLIC markers as well as customary acrylic paints. Pre Priming with Montana Styrofoam primer is required for application on polystyrene. Available in 6 RAL colors. More information on:

VIDEO: WWW.MONTANA-CANS.COM/HOWTO





AVAILABLE CRACKLE COLORS:



EC8004 Copper Brown RAL8004
TNR: 416471



EC5010 Gentian Blue RAL5010
TNR: 416440



EC6000 Patina Green RAL6000
TNR: 418457



EC7000 Squirrel Grey RAL7000
TNR: 418464



EC9010 Pure White RAL9010
TNR: 418488



EC9017 Traffic Black RAL9017
TNR: 418495